



FINISH RINSE AID (400ML)

SKU: RC8502

£4.25 ex VAT

Stock: In Stock Order before 3pm for Next Day Delivery. 16

Finish Rinse Aid is a standard neutral rinse additive. It has been specially formulated for use in a wide range of dishwashers. The product contains a special blend of non-ionic surfactants for rapid, spot, and streak-free drying on all cleaned surfaces in soft and medium-hard water conditions. It promises shinier and drier dishes, to fight water drops, spots and film and give a brilliant shine.

- Helps deliver notably sparkling dishes and cutlery
- Contains a quick dry formula to provide a clean and shiny finish to your dishes
- Finish Rinse Aid works in the rinse cycle to thoroughly remove the detergent and food residues that can otherwise leave spots and stains
- Ideal for domestic or commercial use

[Safety Data Sheet](#)